ROADSIDE INSPECTION GUIDE

DRIVER

To setup the device for the Roadside Inspection for DOT Inspectors:

- Select **Menu> Roadside Inspection**
- Enter Driver password, select **OK**

To get out of the Roadside Inspection mode:

- Select **Menu>Roadside Inspection**
- Enter Driver password, select **OK**

TEAM DRIVERS: Once the inspector has viewed one driver's logs, that driver logs out of inspector mode. Then, select "Switch Drivers" under "Team Driver Share" menu. The second driver logs into roadside inspection mode for the inspector to view logs.

INSPECTOR

To view the driver's logs:

- Select **Menu>System Menu>Reports>Duty Status**
- **To view the grid for that day while on Duty Status screen:**
  - Select the Log Date to be viewed from the dropdown menu
  - Use the screen to scroll from left to right and/or up & down
  - Select **Done** to get out of the grid and back to the Duty Status
    - Or use the 'Back' Arrow to return to the main menu

To view the weekly recap of Driving/On-duty Hours:

- Select **Menu>System Menu>Reports>Daily Hours**
- Select **Done** to get back to the main menu

To view any Failure Reports:

- Select **Menu>System Menu>Reports>Failure Reports**
- Select the date to view
- Select **Done** to get back to the main menu

To view the Location Codes (if location codes are present on driver's logs):

- Select **Menu>System Menu>Reports>Location Codes**
- Select **Done** to get back to the main menu

504871 (Rev. 3/13)

ROADSIDE INSPECTION GUIDE

DRIVER

To setup the device for the Roadside Inspection for DOT Inspectors:

- Select **Menu> Roadside Inspection**
- Enter Driver password, select **OK**

To get out of the Roadside Inspection mode:

- Select **Menu>Roadside Inspection**
- Enter Driver password, select **OK**

TEAM DRIVERS: Once the inspector has viewed one driver's logs, that driver logs out of inspector mode. Then, select "Switch Drivers" under "Team Driver Share" menu. The second driver logs into roadside inspection mode for the inspector to view logs.

INSPECTOR

To view the driver's logs:

- Select **Menu>System Menu>Reports>Duty Status**
- **To view the grid for that day while on Duty Status screen:**
  - Select the Log Date to be viewed from the dropdown menu
  - Use the screen to scroll from left to right and/or up & down
  - Select **Done** to get out of the grid and back to the Duty Status
    - Or use the 'Back' Arrow to return to the main menu

To view the weekly recap of Driving/On-duty Hours:

- Select **Menu>System Menu>Reports>Daily Hours**
- Select **Done** to get back to the main menu

To view any Failure Reports:

- Select **Menu>System Menu>Reports>Failure Reports**
- Select the date to view
- Select **Done** to get back to the main menu

To view the Location Codes (if location codes are present on driver's logs):

- Select **Menu>System Menu>Reports>Location Codes**
- Select **Done** to get back to the main menu

504871 (Rev. 3/13)

J. J. Keller & Associates, Inc. certifies that the J. J. Keller Mobile™ system satisfies all requirements specified in 49 CFR Part 395.15, when kept in proper working condition and used according to the user manual for the system. J. J. Keller & Associates, Inc. is not responsible for driver entry errors or systems not kept in proper working condition.

J. J. Keller & Associates, Inc. certifies that the J. J. Keller Mobile™ system satisfies all requirements specified in 49 CFR Part 395.15, when kept in proper working condition and used according to the user manual for the system. J. J. Keller & Associates, Inc. is not responsible for driver entry errors or systems not kept in proper working condition.